



# Rii i25 IR Programming Steps

## ■ How to program the remote?



- 1 . Press the SET button for more than 4 seconds, the yellow LED will blink once and lit.




- 2 . Align the Rii remote IR Light with the original remote IR Light (note: distance less than 7cm). Then, press the key to be programmed, LED indicator will flash twice and be on, which means the key is ready for programming.



- 3 . Press the key to be programmed in the original remote, Rii remote LED will flash three times and be on, indicating the programming is completed. (In the key learning mode within 10 seconds if the button is not pressed to learn, it will exit the learning state)



- 4 . Repeat steps 2-4 and finish the programming for other keys.
- 5 . Press Set or leave it without any operation 10 seconds, Rii remote will exit programming mode.



Note: The remote control can only support a remote control.